# PRODUCT



## **INFORMATION**



### SERIES 3800/4300 Chemical Vapor Deposition Chemical Vapor Infiltration Graphite Purification Graphitization VACUUM/CONTROLLED ATM FURNACE

Centorr/Vacuum Industries high temperature, low pressure CVD furnaces provide stable, repeatable conditions for production of high performance materials from vapor phase feedstocks involving reaction temperatures up to 2200°C.

Our line of ultra-high temperature furnaces for graphite purification and graphitization are rated for use up to 2900°C. Operation in vacuum inert gas, or Chlorine gas is available.

Furnaces are available as complete systems arranged to handle feedstock gases, provide control of the reaction environment and capture effluents safely and effectively.

#### **KEY FEATURES AND BENEFITS**

- Cold Wall Vacuum furnace design with stainless steel inner and outer jackets with baffled water cooling, designed for easy loading and unloading.
- Graphite resistance heated hot zones withstand harsh CVD environments.
- Induction heating available for Carbon CVI applications or ultra-high temperatures.
- Vertical top and bottom loading furnaces available as well as horizontal rectangular configurations depending on workpiece size, shape, and quantity.
- Operation to 2900°C utilizing state of the art induction heating power supplies. Resistance heated systems for lower temperatures.
- Vacuum pumping systems include mechanical pumps/blowers, and optional liquid ring or dry pumping systems operating in conjunction with feedback loop controlled throttling valves providing constant pressure over a wide capacity range. Particulate filters protect against abrasion.
- PLC with Industrial Programmable Controller or PC system using Intellution<sup>™</sup> FIX32 HMI software customized by Centorr/Vacuum Industries for vacuum furnaces, with extensive data acquisition, and remote operation capabilities.
- Inert and process gas systems utilizing electronic mass flow control provide accuracy, reproducibility, and flexibility for critical CVD applications. Multiple injection nozzle locations allow for adjusting flow patterns depending on the workload.
- Optical Pyrometers available to minimize thermocouple exposure. Corrosion resistant heated manometers provide absolute pressure sensing, independent of gas composition.



Centorr/Vacuum Industries, Inc. 55 Northeastern Boulevard, Nashua, NH 03062 Toll Free: 800-962-8631 Tel: 603-595-7233 Fax: 603-595-9220 web: www.centorr.com email: sales@centorr.com

# SERIES 3800/4300 CVD / CVI / CC

- Highest Product Consistency is assured by the close temperature gradients and automatic temperature control of each step in the process.
- Lowest Cost Operation is provided by the rapid heatup step, unattended operation, fast cooldowns.
- Flexibility is provided by the programmable controls which allow different materials and part sizes to be successfully processed without time-consuming adjustment of furnace conditions.
  - Minimum Maintenance Cost is assured by the heavy construction and ease of access to all components of the furnace.

STD MODEL*	8820	1824	2436	161636	84120
Uniform Effective Hot Zone W x H x L or Dia x H in (mm)	8 x 8 x 20 (200 x 200 x 500)	18 x 24 (460 x 610)	24 x 36 (610 x 914)	16 x 16 x 36 (400 x 400 x 914)	84 x 120 (2133 x 3050)
Workload Volume ft <sup>3</sup> (liters)	.75 (21)	3.5 (100)	9.5 (270)	5.3 (150)	385 (10,900)
Approx. Power Supply Size KVA	45	150	450	275	750
Water Requirements gpm (liters)	7 (26)	30 (114)	65 (246)	43 (163)	125 (473)

\* Custom sizes available upon request.

#### **MISC. / OPTIONAL FEATURES**

- Powered Cover lift for top loading models, and Elevator Hearth for bottom loaders.
- · Effluent capture including scrubbers or liquid ring pumps / dry pumps.

.

- Inert and Process Gas Management and Distribution systems for MTS,  ${\sf BCl}_3,\,{\sf H}_2,\,{\sf CH}_4,\,{\sf and}\,{\sf C}_3{\sf H}_8.$
- · Graphite Retort for containment of process coating, with differential pumping.
- · Work Rotation devices and Gas Injection lances available.
- · Vacuum pump oil filtration systems and vacuum inert gas purge lines.



CVD Instrumentation and Alarm Control Console with mimic panel.

CVD Inert and Process gas cabinet with electronic Mass Flow Controllers.



Series 3800 Model 8820-1600 SiC CVD reactor for advanced ceramics work.

#### FURNACE APPROVALS

Centorr/Vacuum Industries furnaces are designed to our own internal quality standards developed over our 45 year history, and are built to the following industry standards:

ASTM NFPA 86D FM (for G-10503A Hydrogen Systems)



Centorr/Vacuum Industries, Inc. 55 Northeastern Blvd. Nashua, NH 03062 Toll: 800-962-8631 Tel: 603-595-7233 Fax: 603-595-9220 www.centorr.com email: sales@centorr.com